

## Care and Cleaning of Cast Stone Baths

Before fitting your bath: Please remove cardboard packaging and inspect the bath.

**Please note:** shrinkage lines, air holes, casting marks and blemishes on the underside of the bath (where they can not be seen when the bath is turned upright) do not adversely affect performance and should not be regarded as defects.

The fitting of the bath feet and installation of the bath will be seen as acceptance of quality. We strongly recommend that you use a suitably qualified installer. We can not accept responsibility for incorrect installation.

## Care and Maintenance

### Repairing a scratch:

If any scratches occur during installation, these can be removed by rubbing with a 1500+grit waterproof abrasive paper and water.

Repolish the surface afterwards using a neutral automotive color restorer or household metal polish. Deeper scratches may require a more abrasive paper to be used initially. If this is needed, rub the surface with 1500 grid gradually and re polish. For best results limit sanding to the smallest possible area around the scratch.

It may be possible to polish very fine scratches away without using abrasive papers by scrubbing gently with a soft brush or plastic pad (DO NOT use metal scouring pad) and a mildly abrasive cream cleanser. Afterwards scrub the whole area with plenty of clean water and re polish as before.

### Everyday Cleaning of your bath

We recommend that you use a non abrasive bathroom or kitchen household cleaner for your everyday cleaning. Using constantly abrasives may cause the disappearance of the bath satin look dull over a long period of time.

You can clean your bath with an abrasive cleaner, as may be required occasionally, polishing with car polish. Also gumption (all-purpose cleanser) restores the luster of your bath.